

## SIGN FOR MOTORIDENTIFY

When you want to know which north-motor you have got, there are two sign:

1. Application sign on the cylinderhead beetwen the scew.
2. Distance beetwen the waterpump and the cylinderhead

1. 1300 Distance you can see it hardly
2. 1600 Distance ca. 2,5 cm
3. 1750 old series distance ca. 4,0 cm
4. 1750 new series distance ca. 4,0 cm
5. 2000 Distance ca. 4,0 cm

